

CL1042

CL1041

PRODUCT USAGE QUICK GUIDE

Oven & Grill Cleaner

Cleaning ovens and grills



Cleanline Oven & Grill Cleaner is a powerful alkaline fume-free cleaner for the effective removal of carbonised fats, oils and grease from ovens and grills.

AVAILABLE UNIT SIZE(S) & CODES:
CL1041 - 750ml RTU
CL1042 - 5 Litre (Eco-Refill)


SAFE HANDLING:
 Always wear Personal Protective Equipment (PPE) when handling, dispensing and using chemicals.




Refer to the Safety Data Sheet (SDS) for detailed information and immediate first aid measures including medical emergency helpline number.




1 Use appropriate PPE as indicated in the safety data sheet.




2 Prepare area: Ventilate area and place warning/safety signs.




3 Ensure the appliance is powered off and surfaces are cool.




4 Apply Oven Cleaner undiluted on to a cool surface.




5 Leave for 5-20 minutes depending on soil-load.



6 Agitate with a brush or scouring pad to assist with the removal of heavy grease and carbon.



7 Wipe away all soiled traces. Rinse the surface with clean water in a bucket. Repeat rinse to ensure to residue remains.



8 Allow to air dry and remove warning/safety signs.

WARNING: Do not use on aluminium, copper, brass, marble, painted surfaces, appliance lettering, heating element or fan.



Cleanline® is an exclusive brand of Bunzl UK & Ireland

© 2021 Bunzl UK Ltd. All Rights Reserved.